

Pong
Spare Part Kit

Part No.	Description	QTY	
P140-108-000	The Whole Ball Assy	1	
P140-114-001	The Whole Pedal Assy	1	
P140-406-000	Bluetooth amplifier board	1	
P140-409-000	Coder	1	
P140-410-000	White button 1P	2	
P140-411-000	White button 2P	2	
P140-412-000	Orange button	2	
P140-418-000	Light strip	1	
P140-420-001	Multimedia board/TF/battery	1	
P140-421-001	Display board	1	
P140-422-001	Main board	1	
P140-405-001	Sensor SW	2	
P140-456-000	Motor driver(2405)	1	
P140-457-000	Motor driver(2305)	1	
P140-458-000	Hinge	6	
P140-459-000	Hybrid stepping motor(HS 42)	1	
P140-460-000	Hybrid stepping motor(HS 57)	1	

Part No.	Description	QTY	
P140-472-000	Suction cup	1	
P140-424-000	Audio isolator	1	
P140-136-001	Wheel shaft	8	
P140-178-000	Axle wheel	8	
P140-902-000	Jog Assembly	1	
P140-461-000	Belt (meter)	20	
P140-705-000	Side Decal	2	
P140-703-000	Front Decal	2	
P140-704-000	Control panel decal	2	
P140-902-001	Jog	2	
P140-465-000	Strong Magnet1 (inside pedal/machine)	4	
P140-466-000	Strong Magnet2 (inside machine)	2	
P140-467-000	Magnet3(inside the Ball)	2	